



# N-computing setup related

- **NComputing ports information:**




- **How to Assign a Static IP Address in M300 N-computing Device**




After installing the vSpace server at the host PC or Server, it is important to set up The n-Computing device, after connecting the device, please turn on the device (M300 have 3 devices please configuration on the main device which size is bigger than 2 devices)


- At first power on the N-computing server and N-computing device then press **F5**.



- Select the " Device setup" option.




- Then select the " Network Setting" option.




- Select " Static Radio button " and insert IP (Internet protocol), Subnet mask and Gateway.

Ex. - The IP address 192.168.1.4, subnet mask 255.255.255.0, Gateway 192.168.1.14.



- After filling all the blocks of IP click on the Apply button.
- And finally, click on the save button to save all the changes.



- Now Server will show up on the home screen of the M300 N-computing setup.

- **N-computing issues and solutions:**
  - **Issue: Cannot connect to Host**
-

Revision #6

Created 30 March 2020 10:56:39 by Raju Sambari

Updated 6 April 2020 10:39:38 by Raju Sambari